LEVER	WHEN	LOCKS
1	SPARE LEVER	
2		4 9 11 (18) 25
3		9 (16) 24
4		9 11 25
	14	(18)
	(14)	26 27 29
	(14) 19	(21)
5		14 26 27 29
	9 19	(21)
	(9) 16	(18) 25
	(9) (16)	24
6	SPARE SPACE	
7	SPARE SPACE	
8		11 (11) 16 24 28
	(11) 14	(18) 25
	(11) (14)	26
	(11) (14) 19	(21)
9		11 14
10	STUB LEVER	
11		
12	STUB LEVER	
13	SPARE LEVER	
14		11 (11)
	11	58 61 71
15	STUB LEVER	
16		9 (9) 11 14 58 61 71

LEVER	WHEN	LOCKS
17	STUB LEVER	
18		11 (11) 14 16
	11	9 (9) 58 61 71
19		9 14 (14)
	14	58 61 71
20	STUB LEVER	
21		9 14 (14) 19
	14	58 61 71
22	SPARE SPACE	
23	SPARE SPACE	
24		11 16 (16)
25		(18)
26		(19)
27		(21) 29
	(14)	11
28		(11) (14) (21) 27 29
29		14 (21)
30	SPARE LEVER	
31		46
32	STUB LEVER	
33		
34	STUB LEVER	

LEVER	WHEN	LOCKS
35		(41)
	33 48 53 94	(96) 101
	33 48 53 (94)	(97) 102
	33 48 (53)	(97) 102
	33 (48)	56 59
	(33) 43 50	56 59
	(33) 43 (50) 53 94	(96) 101
	(33) 43 (50) 53 (94)	(97) 102
	(33) 43 (50) (53)	(97) 102
	(33) (43)	60 63
36		(42)
	31 46	(97) 102
	31 (46) 48 53 94	(96) 101
	31 (46) 48 (53)	(97) 102
	31 (46) 48 53 (94)	(97) 102
	31 (46) (48)	56 59
	(31) 33 48 53 94	(96) 101
	(31) 33 48 53 (94)	(97) 102
	(31) 33 48 (53)	(97) 102
	(31) 33 (48)	56 59
	(31) (33) 43 50	56 59
	(31) (33) 43 (50) 53 94	(96) 101
	(31) (33) 43 (50) 53 (94)	(97) 102
	(31) (33) 43 (50) (53)	(97) 102
	(31) (33) (43)	60 63
37		(55) 60 63
	(39) 50	56 59
	(39) (50) 53 94	(96) 101
	(39) (50) 53 (94)	(97) 102
	(39) (50) (53)	(97) 102

LEVER	WHEN	LOCKS
38		(45)
	43 50	56 59
	43 (50) 53 94	(96) 101
	43 (50) 53 (94)	(97) 102
	43 (50) (53)	(97) 102
	(43)	60 63
39		33 43 48
40	STUB LEVER	
41		31 33 (33)
	33	46 48 (48)
	33 48	50 53 (53) 75 83
	33 48 53	93 94 (94)
	(33)	43 (43)
	(33) 43	48 50 (50)
	(33) 43 (50)	53 (53) 75 83
	(33) 43 (50) 53	93 94 (94)
42		31 (31)
	31	46 (46)
	31 46	53 75 83 94
	31 (46)	48 (48)
	31 (46) 48	50 53 (53) 75 83
	31 (46) 48 53	93 94 (94)
	(31)	33 (33)
	(31) 33	48 (48)
	(31) 33 48	50 53 (53) 75 83
	(31) 33 48 53	93 94 (94)
	(31) (33)	43 (43)
	(31) (33) 43	48 50 (50)
	(31) (33) 43 (50)	53 (53) 75 83
	(31) (33) 43 (50) 53	93 94 (94)
43		50
44	STUB LEVER	
45		33 39 43 (43)
	43	48 50 (50)
	43 (50)	53 (53) 75 83
	43 (50) 53	93 94 (94)
46		

LEVER	WHEN	LOCKS
47	STUB LEVER	
48		50
49	STUB LEVER	
50		
51	STUB LEVER	
52		(58)
53	PLUGGED IN NORMAL	50 (50) 94
54	STUB LEVER	
55		39 (39) 43
	(39)	50 (50)
	(39) (50)	53 (53) 75 83
	(39) (50) 53	93 94 (94)
56		50
	48	43
	48 39 33	(45)
	48 39 (33) 31	(41)
	48 39 (33) (31)	(42)
	48 (39)	(55)
	(48) 46	33
	(48) 46 31	(41)
	(48) 46 (31)	(42)
	(48) (46)	(42)
57	SPARE SPACE	
58		
59		(52)
60		(64) 65

LEVER	WHEN	LOCKS
61		
62		(52) 56 59
63	43	39 (55)
	(43) 33	(45)
	(43) (33) 31	(41)
	(43) (33) (31)	(42)
64		(61)
65		63 (64)
66	SPARE SPACE	
67	SPARE LEVER	
68		58
69	SPARE LEVER	
70		68 (73) (84)
	(75)	(90)
71		
72		(68) (73) (84)
	(75)	(90)
73		75 (75) 85 86
	75	77 (77)
	75 (77)	101
	75 (77) (94)	(97) 102
	(75)	(90)
74	SPARE SPACE	
75		
76	SPARE SPACE	
77		75 (93) 94 (94)

LEVER	WHEN	LOCKS
	94	(96)
	(94)	(97)
78	STUB LEVER SPARE	
79	SPARE LEVER	
80	SPARE SPACE	
81	SPARE LEVER	
82	STUB LEVER-SPARE	
83		(75)
84		(71) 68 (68)
85		(84)
86		75 77
87	SPARE LEVER	
88		(83) 83
89		83 88
90		88 (83)
91	SPARE SPACE	
92	SPARE SPACE	
93		
94		
95	STUB LEVER	
96		94
	93	53 50 (50)
	93 50	48

LEVER	WHEN	LOCKS
	93 50 46	33
	93 50 46 31	(41)
	93 50 46 (31)	(42)
	93 50 (46)	(42)
	93 (50) 39 33	(45)
	93 (50) 39 (33) 31	(41)
	93 (50) 39 (33) (31)	(42)
	93 (50) (39)	(55)
97	94 53	31 (42) 46
	94 (53)	50 (50)
	94 (53) 50	48
	94 (53) 50 46	33
	94 (53) 50 46 31	(41)
	94 (53) 50 46 (31)	(42)
	94 (53) 50 (46)	(42)
	94 (53) (50) 39 33	(45)
	94 (53) (50) 39 (33) 31	(41)
	94 (53) (50) 39 (33) (31)	(42)
	94 (53) (50) (39)	(55)
	(94) 93	53 50 (50)
	(94) 93 50	48
	(94) 93 50 46	33
	(94) 93 50 46 31	(41)
	(94) 93 50 46 (31)	(42)
	(94) 93 50 (46)	(42)
	(94) 93 (50) 39 33	(45)
	(94) 93 (50) 39 (33) 31	(41)
	(94) 93 (50) 39 (33) (31)	(42)
	(94) 93 (50) (39)	(55)

REVISIONS
10-25-57

DRAWN BY
CHECKED BY
APPROVED
SUPT. SIGS.
REDRAWN-8-26-57
(MM57010)

CORWITH, ILL. → SD 96A
→ SD 94A
LOCKING SHEET
OFFICE OF SUPT. SIGS.
G.M.& O.R.R. BLOOMINGTON, ILL.

W. A. Plan
0 0 0 In XXX Out
Date
Office of Engineer - Signals & Electrical
I. C. G. Railroad Chicago, Illinois
For

LEVER	WHEN	LOCKS
98	SPARE SPACE	
99	SPARE SPACE	
100	SPARE SPACE	
101		(96)
	(93)	(77)
102		(97)
	(93) (94)	(77)
103	SPARE SPACE	
104	SPARE SPACE	